

Register change of position



1 Unlock buttons

- Press the keylock button
- The indicator light illuminates steadily, the buttons are unlocked

2 Register change of position

- Press the repositioning button
- The indicator light flashes green, the position change is registered



Register change of position



1 Unlock buttons

- Press the keylock button
- The indicator light illuminates steadily, the buttons are unlocked

2 Register change of position

- Press the repositioning button
- The indicator light flashes green, the position change is registered



Acknowledge alerts




1 Unlock buttons

- Press the keylock button
- The indicator light illuminates steadily, the buttons are unlocked

2 Acknowledge alert

- Press the button of the active alert (red blinking indicator light)
- The red light goes off, the alert is acknowledged



Acknowledge alerts



1 Unlock buttons

- Press the keylock button
- The indicator light illuminates steadily, the buttons are unlocked

2 Acknowledge alert

- Press the button of the active alert (red blinking indicator light)
- The red light goes off, the alert is acknowledged

